USB DFU Update procedure for driver 4.82.0. The latest driver MUST be installed for this to work correctly.

Step 1.

Open the application **MSB_ProUSB_DFU_Tool.exe**.

This is the first page you see. Verify that the **Current Firmware:** version is older than version v2.00

Step 3.

If the **Current Firmware** is older than the new update file, click the start button. The data will transfer and once complete, you will only be able to “Exit” the DFU tool